

# EF3751F-48H2 User's Guide

Susei Electronics System Co., Ltd  
First edition issued February, 2002

## 1. General Description

EF3751F-48H2 is a Flash MCU programming adapter designed for the programmer main unit, EFP-I. The adapter (EF3751F-48H2) installed on the top of the programmer (EFP-I) allows user to program Renesas 8-bit Flash MCUs, specifically for 3751 Group MCUs. The adapter is equipped with a 48-pin clamshell socket supporting 48-pin 0.5mm QFP package (Type No: 48P6Q-A).

<Packing contents>

- 1) EF3751F-48H2
- 2) Users guide (this manual)

Figure 1.1 shows the adapter appearance.




Figure 1.1: Appearance of EF3751F-48H2

## 2. Insertion Direction of MCU and cleaning of IC socket

### 2. 1 Insertion Direction of MCU

To program the MCU, the MCU must be mounted on the socket and latch the clamshell top. The MCU orientation must be properly matched to the socket. Figure 2.1 shows the location of pin No. 1 on the socket. Incorrect MCU insertion may damage the MCU.




Figure 2.1: Pin Orientation of The socket

### 2. 2 Cleaning of IC Socket

A contact pin inside of the IC socket of the MCU unit might deteriorate and a contact failure might occur because of the number of times used and its age of service. As the contact failure may cause incorrect writing of MCU and malfunction of the writer, please take the below measures.

#### Measures against IC Socket Contact Failure

- (i) Please clean the contact pin surface inside of IC socket with a brush, etc. regularly, depending on the number of times used.
- (ii) If the product is not to be used for a long period, please keep it with less humidity in a plastic bag, etc.

Though enquiries on contact failures can be made, we regard IC sockets as consumable supplies. We may recommend you to replace them if a contact failure of IC socket occurs due to its use deterioration.

#### 【Recommended item for cleaning】

About the cleaning of the contact pin in the IC socket, we recommend the use of the nanotech brush (Kita Mfg Co., Ltd).

The nanotech brush can remove the dirt which stuck to a contact pin, a very small amount of metastasis of solder. When a contact poor problem occurred, please try it.

About nanotech brush, please ask us or Kita Mfg Co., Ltd (refer to the following site).

Nanotech brush (Kita Mfg Co., Ltd.) [http://www.kita-mfg.com/pro\\_nanotech\\_e.html](http://www.kita-mfg.com/pro_nanotech_e.html)

### 3. Specifications

Specifications of the EF3751F-48H2 are listed in Table 3.1.

Table 3.1: EF3751F-48H2 Specifications

MCU Type	Memory Type	Corresponding MCU Name	Program Memory Area
M3751 x F8 (BOOT)	Flash memory	M37517F8HP	F000H-FFFFH
M3751 x F8 (NORMAL)	Flash memory		1000H-FFFFH
Remarks Power source: Supplied from EFP-I Do not change the setting of the SW switch when the EFP-I' s device LED(red) is it.			

#### 2. 2 About Software version(S/W)

The version numbers such as EFP-1 and WinEFP are displayed by [Help]→[About] in the WinEFP window menu. Please download the latest version up data on the following site when the S/W version such as EFP-I used is old.

< EFP-I S/W the latest free download site >

[http://www.suisei.co.jp/download\\_e/productdata\\_efp1\\_e.html](http://www.suisei.co.jp/download_e/productdata_efp1_e.html)

< EFP-S2 S/W the latest free download site >

[http://www.suisei.co.jp/download\\_e/productdata\\_s2\\_e.html](http://www.suisei.co.jp/download_e/productdata_s2_e.html)

< EFP-S2V S/W the latest free download site >

[http://www.suisei.co.jp/download\\_e/productdata\\_s2\\_e.html](http://www.suisei.co.jp/download_e/productdata_s2_e.html)

#### Note on Corresponding Versions

Above corresponding versions might change without notice on account of the future capability improvement, etc. Furthermore in case the upgrade procedure manual is attached when this product is purchased, please refer to that manual as a priority.

#### 4. Erase Command

The erase type parameter contained in the erase command enables you to erase by block or erase all blocks. The erase command parameter input dialog is shown in Figure 4.1.

\*This command has not been described in the WinEFP manual.



Figure 4.1: Erase Command Parameter Input Dialog

**(1) Erase type**

All Erase and block address area (xxxxxxH - xxxxxxH) are displayed in the drop-down list to the right of the erase type parameter display field (displayed by clicking the arrow pointing downward with the mouse). Select the block erase method.

**(2) OK button**

Execute the block erase command.

**(3) Cancel button**

Cancel the command.